

COUCH ASSEMBLY
Locating and installing the legs


REQUIRED

2-Persons



INCLUDED

Couch Legs X2





Bolts X4




Washers X4




Allen Key




Remove the legs from the box inside the packaging.




Turn the sofa on the backside.



Use the Allen key with to fix the legs to the couch by turning the bolts with washers into the fittings underneath.



No adjustment needed as legs will fit in place after tightening.



Carefully, turn the sofa upright and ensure that each leg is installed properly.