

COUCH ASSEMBLY
Locating and installing the legs

REQUIRED

2-Persons




INCLUDED

Couch Legs X4


Bolts X8

Washers X8

Allen Key




1



Remove the legs from the box inside the packaging.




2




Turn the sofa on the backside.

3




Use the Allen key with to fix the legs to the couch by turning the bolts with washers into the fittings on each corner.

4



Adjust legs to be even on the sides before tightening.

5



Carefully, turn the sofa upright and ensure that each leg is installed properly.