





Remove the legs and long rails from packaging. Insert the threaded rod into the pre-installed fitting next to the wood dowel by turning it clockwise by hand.







Turn both legs upside down and insert the threaded rods into pre-drilled holes of the long rails. The big holes should be facing upwards to tighten the fitting.

Insert the half moon washer and nut onto the threaded rod visible through the hole at the ends of the rails.

Tighten the nut with the mini wrench provided.



Insert threaded rods into pre-installed fittings on top of legs. Lower the assembled frame onto the top. The threaded rods will slide into pre-drilled holes in the top rail and will be in position to tighten.



Insert the half moon washers and nuts (2 per leg) and tighten until secure. Carefully, turn the table upright and ensure that not to rest the table on its side while doing so.